




Absolute Digital Readout



user's manual ver.2020.03





CONTENTS

| Description of DSC800 counter | |
|--------------------------------------|--------------|
| 1. Front panel | 1-1 |
| 2. Back panel | 1-2 |
| 3. Wire connection | 1-3 |
| 4. Description of buttons | 1-4 |
| Basic operation | |
| 1.Preset | 2-3 |
| 2. Recall preset value | 2-3 |
| 3. Reset(Display Zero) | 2-4 |
| 4. Half (1/2) function | 2-4 |
| 5. inch/mm Conversion | 2-4 |
| 6. INCR/ABS Conversion | 2-5 |
| 7. Bolt hole circle | 2-11 |
| 8. Axis setting for bolt hole circle | |
| (1) Setting as X & Y | 2-15 2-16 |


9. OPEN/ERROR ------ 2-18

Function

| 1. Changing Resolution (SCALE) (1) 5 / 1000(2) 1 / 1000 | 3-1 3-1 |
|---|------------|
| 2. Changing direction | 3-1 |
| 3. Rate or Correction (5.rAtE) | 3-2 |
| 4. Reset function (7.rESEt) | |
| (1) ABS reset | 3-4 |
| (2) Program reset | 3-5 |
| 5. Testing FND (8.tESt) | 3-6 |
| 6. Adding up Z & Q axes(10. qAdd) | 3-7 |
| 7. Vibration proof function | |
| 8. Decrease of decimal place | 3-10 |
| Lathe function | |
| 1. Summing of two axes | 4-1 |
| 2. Double counting function | 4-2 |
| 3. Tool offset | 4-4 |
| EDM function | |
| 1. Key operation | 5-2 |
| 2. Output Signal of DSC-803EDM Counter | 5-3 |
| 3. How to input numerals | 5-4 |
| 4. Changing Discharge Directions | 5-5 |
| 5. To check present value of EDM mode as in normal mode | 5-8 |
| Installation of linear scale and trouble shooting | |
| 1. Installation | 6-1 |
| 2. Trouble shooting | 6-6 |
| 3. Replacing a fuse | 6-7 |
| 4. Connectors' information | 6-8 |
| 5. RS232 transmission format | 6-8 |

DESCRIPTION OF DSC-800


1. Front Panel



| Keys | Descripton |
|---|---|
| 1. Display area 2. Axis indication lamp 3. Zero set keys 4. Axis indication key 5. Numbers key 6. Function Key 7. ON/OFF switch 8. Subsidiary display area 9. Function lamp | Diplay the values of X, Y and Z axis Lamp will be on when the axis selected Initializing key To select the axis 0 ~ 9 numbers To begin any function, firstly start with "F" Turn on / off the display unit Display when "ABS" or Bolt hole circle selected Lamp will be on when a function selected |


Note) This manual explains every function on the basis of 3-axis display unit (DSC-803).

2. Back Panel



| Keys | Descripton |
|--|---|
| 1. Main power switch 2. Fuse 3. Connectors for scale 4. GND 5. AC supply power | ON/OFF the main power 220V/1A Connections for X, Y and Z axes Ground connector Connection with a power cord |

3. Wire connection



4. Description of buttons

| Key | Name | Description | |
|-------------|-------------------------------------|---|--|
| Xo Yo Zo | Axis zero key | Reset present displayed axis | |
| XYZ | Axis (indication) key | Select axis | |
| 0~9 | Number key | Numbers of 0 ~ 9 | |
| • | Dot key | Input the value of decimal point | |
| <u>+/</u> | +/- key | Changing positive(+) or negative(-) value | |
| ENT | Enter key | "Enter" means completion of the process | |
| I | Backward / Forward | When using "Menu" or "Function", move by sequence. Use this to look for the number of ABS or Bolt hole circle. | |
| CE | Cancel key | Cancel input processing. Cancel excuting operation. Clear the error. | |
| F | Function key | To use any function, firstly push "F" key | |
| 1/2 | 1/2 key | Divide present value into a half | |
| PRE | Preset Recall | Recall memerized coordinates | |
| | Multiple Datum Point function | To set multi datum point (abs function in incremental display) | |
| \bigoplus | Bolt hole circle | To use Bolt hole circle function | |
| INCH | Mm / inch | Changing mm / inch | |
| (| On / Off key | Turn on / off the FND display | |



BASIC OPERATION

Power ON / OFF


For general use, leave the main switch always ON, use ON/OFF switch of the front side.

System will be on after 3 seconds of turning on.


• Main switch of the rear side




• ON/OFF switch of the front side




ON/OFF switch. If the switch of rear side is on, inside circuit is still working even when this switch is off.



1. Preset



2. Recall preset values




3. Reset (Display Zero)

| Xo Yo Zo | | To make ea | ach axis zero |
|----------|-----|-------------------------|---------------|
| Ex. | | | |
| 4 | X Y | 0.000 0.000 0.000 | |


4. 1 / 2 Function (dividing into a half)


| X - 1/2 | | To divide a | value into a half |
|-------------------------------------|-------|-------------------------|-------------------|
| Ex.) To divide "12.400" into a half | | | |
| Input or recall "12.400" | X Y Z | 12:400 0000 0000 | |
| X 1/2 | X Y Z | 6.200 0.000 0.000 | |


5. inch/mm conversion





6. INCR/ABS Conversion (multiple datum point)















7. Bolt hole circle



There are 4 factors for Bolt hole circle.

- 1) Radius (R), or Diameter(d)
- 2) The number of holes: d-no
- 3) Start angle: Sph 4) Final angle: Eph

Details for 4 factors (imputable range)


| Factors | Available range |
|--------------------------|------------------------------|
| Radius(r) or diameter(d) | +8000.999mm or +400.9998inch |
| The number of holes | 2 ~ 99 holes |
| Start angle (Sph) | 0.000 ~ 359.999 |
| Final angle (Eph) | 0.001 ~ 999.999 |
| | |



Normal mode

An example of a bolt hole circle

Axis setting = X & Y axis Radius(r) = 10.0The number of holes = 8Start angle = $0^{\circ}.0^{\circ}$ Final angle = $360^{\circ}.0^{\circ}$



Note

Before setting for bolt hole circle, a datum point should be defined.

Input 4 factors \rightarrow move worktable \rightarrow X & Y-axis window display "0.000" \rightarrow find next hole by pushing \blacktriangleright key.

By using • keys, the position (or ABS no.) of previous or next hole can be found easily.

Bolt hole circle is unavailable in the 1-axis display unit


Please do not move worktable during inputting factors.

| | z 30.100 |
|-------------------|-----------|
| X_0 Y_0 Z_0 | x 0.000 |
| | y 0.000 |
| | z 0.000 |
| \bigoplus | x cir rAd |
| | y 0.000 |
| | z 0.000 |
| | CIR |
| 1 0 | x clr rAd |
| | Y 10.000 |
| | z nono |

X


— Blinking


CIR



- NOTE -
- * Processing direction is counterclockwise.
- * Final angle should be added 360 to the start angle.

Final angle (°) = Start angle + 360






8. Axis setting for Bolt hole circle

1). Setting as X & Y-axis

| $F \rightarrow \blacktriangleright \rightarrow ENT \rightarrow ENT$ | | Only availa | ble in 2, 3 and 4-axis display unit. |
|---|------------------------|---------------------------------|--------------------------------------|
| F | Y Z | 7£ E 0.000 0.000 | |
| | X | 1rclE 0.000 0.000 | |
| ENT | x <i>(A)</i> Y z | ## 4 15 HY 0.000 0.000 | |
| ENT | X | 0.000 0.000 0.000 | |

1). Setting as X & Z-axis



3). Setting as Y & Z-axis

| | | Only availab | le in DSC-803(3-axis), 804(4-axis) display unit. |
|-----|-------------------|-------------------------|--|
| F | Y | 0.000 0.000 W | |
| | Y | 0000 0000 0000 | |
| ENT | Y | 0.000 0.000 0.000 | |
| | x 2.84 Y z | 0.000 0.000 0.000 | |
| | x 3.8 H Y z | 0.000 0.000 | |
| ENT | X Y Z | 0.000 0.000 0.000 | |

4). Setting as Radius & Diameter

| $F \rightarrow \triangleright \rightarrow ENT \rightarrow \triangleright \rightarrow \triangleright$ | → ENT Only av | vailable in DSC-802, 803, 804 display unit. |
|--|--|---|
| F | x (LAEE y 0.000 z 0.000 | |
| | x <u>2.c ircle</u> y <u>0.000</u> z <u>0.000</u> | |
| ENT | x (AH 15 H) y 0.000 z 0.000 | <u>7</u> |
| | x <u>2.8H 15 H 3</u> y <u>0.000</u> z <u>0.000</u> | |
| | x <u>38H 15 93</u> y <u>0000</u> z <u>0000</u> | $\overline{\mathcal{I}}$ |
| | x 4d 18-c80 y 0000 z 0000 | (Bolt note circle) |
| ENT | x <u>0000</u> y <u>0000</u> z <u>0000</u> | $ \overline{\mathcal{G}} $ |

9. OPEN / ERROR

OPEN shows when there is wire cut or no connection between a display and a scale.

ERROR shows when there is reading problem from a linear scale.

There is no scale connected in X-axis of a display unit.

| X | oPEn |
|---|-------|
| Y | 0.000 |
| Z | 0.000 |

x <u>Error</u> y <u>42715</u> z <u>1360</u> This means cable of a scale is cut or disconnected.

Measured value error due to dirt or foreign body in a scale.

Measured value error due to damage or scratch of a glass scale

Cause of Error and solution

| Cause of Effor and solution | | | | |
|-----------------------------|---|--|--|--|
| Symptom | Cause | Solution | | |
| Inaccuracy | Foreign body in a scale. Lubrication oil in a scale. Loose connection of a scale. No ground. Lubrication in joint of extension cable. Wrong operation for Rate or Resolution. Breakdown of glass, reading head or flexible cable. | Remove the foreign body. Remove the lubrication oil. Tighten up the connectors. It needs grounding. Clean up the joint part. Operate "RATE" or "Resolution" Otherwise, contact your local service. | | |
| No counting | Electric shock from outside. Wrong operaion for input "RATE". | Check the ground. Correct "RATE" | | |
| "OPEN" message | There is no connection. Wire is cut. | Make sure the connection and wire cut. Otherwise, contact your local service. | | |

DC

FUNCTION

| All of operation for function starts from F key | F |
|--|---|
| F 1. LATHE: Summing function for lathe (4-1) 2. CIRCLE: Bolt hole circle (2-11~17) 3. SCALE: Changing resolution (3-1) 4. DIR: Changing processing direction (3-1) 5. RATE: Rate, Correction or Compensation. (3-2) 6. DIA: Double counting for lathe (4-2) 7. RESET: Initializing function (3-4) 8. TEST: FND (Flexible Numeric Display) testing (3-6) 9. QADD: adding up Q & Z axes (3-7) 10. Display: decrease of decimal place (3-10) | |


1. Changing resolution (SCALE)

 $\label{lem:Resolution} \textbf{Resolution is already set from factory.}$


No need to change resolution in this ABS digital readout.

5/1000 or 1/1000 has been set from factory.


2. Changing direction (4.dlr)




3. Rate or Correction (5.rAtE)



Correct or Compensation









| X | x l | 000000 |
|---|------|---------|
| | y 58 | L AH 15 |
| | z | 0.000 |
| | | FUN |

| ENT | x (000000 | |
|-----|----------------|--|
| | y SEL AH IS | |
| | z <i>0.000</i> | |
| | FUN | |


| 0 • 9 9 6 | x <u>0996000</u> Y <u>5EL AH 15</u> |
|-----------|--|
| | z 0.000 |
| | FUN |

| ENT | x | 0.000 |
|-----|------------|-------|
| | Υ | 0.000 |
| | Z [| 0.000 |


4.Reset function (7.rESEt)

1) ABS Reset (Delete ABS data)


(Here, ABS means "Multiple datum point")



2) Program Reset (Delete all saved data)




5. Testing FND (8.tESt)




6. Adding up Z & Q axes(10. qAdd)

Z-axis:


Q-axis:






 \rightarrow ENT \rightarrow \bigcirc \bigcirc \bigcirc \bigcirc \bigcirc (or \bigcirc \bigcirc) \rightarrow ENT \bigcirc


 $\blacksquare NT \rightarrow \boxed{Q} \rightarrow \boxed{\blacktriangleright} (or \boxed{\blacktriangleleft}) \rightarrow \boxed{ENT}$



7. Vibration proof function




8. Decrease of decimal place (12 Display)





DC

LATHE FUNCTION





1. Lathe Summing Function (1.LAthE)







2. Double Counting Function (6.dIA)






3. Tool Offset








EDM Function

D


BASIC OPERATION

► How to operate 803 AEDM



| Keys | Name | Description |
|------|----------------------------|--|
| EDM | EDM | To begin EDM Mode from Normal Mode |
| SET | SET | To set the discharge direction up or down in normal and EDM mode. |
| ▶,◀ | Step Key or Up-Down Key | To move to the next discharging step To use when discharge ready To set discharge direction up or down |
| ENT | ENT | Push ENT after inputting data |

1. Key Operation



<NOTICE> If you want to repeat the same processing after a discharging cycle, don't forget to push key. Then "1" will be shown in the subsidiary display area.


► <Ex.1> When you input data in EDM mode,


X and Y axis display windows show EDM related information.

- X-axis window: shows 'STEP-1' (to 'STEP-4')
- Y-axis window: shows numerals you will input
- <Ex.2> When you start discharging,

X and Y axis display windows show processing related information.


- X-axis window: shows numerals assigned to each STEP.
- Y-axis window:
 - (1) set as Down: firstly shows numerals which is the smallest in the pre-set values.
 - (2) set as Up: firstly shows numerals which is the biggest in the pre-set values.





- ▶ When discharging of every step is finished, numerals will disappear from the subsidiary display area.
- ▶ If you input values at random regardless of the STEP;
 - (1) In case it was set as UP: the smallest value will be automatically assigned to STEP No.1 and the rest in order.
 - (2) In case it was set as DOWN: the biggest value will be automatically assigned to STEP No.1 and the rest in order.

2. Output Signal of DSC-803AEDM Coutner




▶ In STEP-1 ~ STEP-3, EDM counter will out a relay signal momentarily but, in SETP-4, the relay signal will be out continuously when Z-axis moves down over the value of STEP-4.


In other words, a relay signal will be out continuously,

- (1) If it has been set as 'UP': when the value of Z-axis is bigger than the value of STEP-4.(2) If it has been set as 'DOWN': when the value of Z-axis is smaller than the value of STEP-4.


3. How to input numerals




4. Changing Discharge Directions




- ▶ When you set discharge direction 'UP', the value you will input should be bigger than present Z-axis value. In case of 'DOWN', the value should be smaller than the Z-axis value.
- ▶ If the STEP values go down though you set the direction 'UP', please change 'counting direction' from (-) to (+) or reversely.
 - * 'Counting direction' is for the direction of a Linear Scale, while discharge direction is for the direction of an EDM counter(Z-axis moving)
 - * How to change 'counting direction' (see "'page 31" for more)
 - 1. Make sure if the counter is in normal mode.
 - 2. Push F button, then select '4.dir' from the menu and push [M] key.
 - 3. Push **z** button. (the axis you want to change directions)
 - 4. Push ▶or ◀ to change present direction to opposite direction.
 - 5. Push Into complete changing directions.






5. To check present value of EDM mode as in normal mode



⚠ Notice



INSTALLATION & TROUBLE SHOOTING

1. Installation

- 1) Installation and precaution
- ① Display counter should be safely grounded.
- ② Do not put the DRO system around other electrical appliances which could cause electrical noise.
- ③ Be careful not to let contaminates like lubrication oil and chips flow into the scale.
- ④ To insure the highest accuracy possible, install the scales as close as possible to the object being measured or the workplace.
- ⑤ It is strongly recommended to install a protective cover and insure that the reading head can move freely and smoothly.
- ⑥ Glass scales can be broken from any shock. Handle with care.
- ① Use the voltage between 110V and 220V.

Required Tools for installation


Electric Drill: φ3.5, φ4.3, φ5.2

Tap: M4, M5, M6 Dial Gauge: 1/100 mm

Tap Handle Screwdriver Wrench set .

Mounting accuracy


Mount a linear scale to be horizontal and perpendicular to each central axis.



3) Mounting scale

(1) Positioning, Drilling, Temporary fixing.


By determining mounting position on mounting surface of machine bed, drill and tap holes. Fix the scale temporarily to the machine table, using the hexagon socket head bolt.



(2) Mounting


Using dial gauge, measure horizontal angle of A.

- 1 Scales over 1000mm, check alignment and if it is fixed in a proper space.
- 1 If the alignment of A don't be measured with Digital Gauge, facing area of alignment mark is parallel in both direction.





(3) Head carrier Mounting

Space between a machine bed and a reading head should be 0.1378" (3.5mm) \pm 0.0039"(0.1mm) for JSM, and 0"(0mm) \pm 0.0039"(0.1mm)mm for JSS or JSN.




• The guard needs to be removed after installation.





 With a mark at the end of scale as a datum line, gap between head and scale should be equal.




2. Trouble shooing

| Trouble | Solution |
|--|---|
| Power was turned off. | Make sure key is turned on. Make sure main power is on. Make sure Fuse has blown out Make sure power corder is connected rightly. |
| Fuse blows out frequently | Make sure supping power is stable or not. Disconnect a scale from the counter and check the connectors. After checking above, call repairing service. |
| Power is on but display is turned off | Cutting fluid or oil can flow into the keyboard. Disconnect a scale from a counter. |
| ERROR is shown in the axis window | Check the connection between a scale and a counter. Check the ground state of a counter. Check the fixing bolts are loosen. Connect the scale with other axis of a counter to see which one is the cause Check backlash of the machine. Check if the scale was broken from being got bent or curved. |
| Displayed value is fixed when a scale is moving | Check "RATE" (32p) Check normal rate is "1000000". Check the connection of a scale and a counter. |
| One out of X,Y and Z-axis doesn't work | Connect the scale with other axis of a counter to see which one is the cause |
| DIA lamp is on | Turn to RAD mode using "Double counting function of lathe" (39p). |
| Displayed value is double counted | Check "RATE" (32p). Check normal rate is "1000000". Check if DIA lamp is on, then do correction as below (39p) |
| Difference between real value and measured value Correction of RATE (32p) | ■ Real distance |
| Note | Be careful cutting fluid, oil or dust not to flow into a scale. |

 $[\]ensuremath{\,\%\,}$ This product can be modified without previous notice to improve quality.

3. Replacing a fuse




Replacing a fuse, 250V 2A. Use a - type screw driver

| Kinds | Standard |
|---------------|-------------|
| Rated Voltage | 110V ~ 220V |
| Fuse | 250V, 2A |

4. Connector information


| Counter | Scale |
|---|---|
| | |
| 1 PIN : + (+5V) 2 PIN : A 3 PIN : B 4 PIN : Z 5 PIN : -(0V) 6 PIN : Shield | 1 PIN: + (+5V) 2 PIN: A 3 PIN: B 4 PIN: Z 5 PIN: - (0V) 6 PIN: Shield |

PIN & Color



| PIN | Color | Signal |
|-------|--------------|--------------|
| 1 PIN | RED | + (+5V) |
| 2 PIN | YELLOW | A (+4.2V) |
| 3 PIN | WHITE | B (+4.2V) |
| 4 PIN | GREEN | Z (+0.4V) |
| 5 PIN | BLACK | - (+0V) |
| 6 PIN | BLACK SHIELD | Shìeld (GND) |

PIN for DSC-703EDM Counter



5. RS232 transmission format

1. OUTPUT CODE

RS-232: 115200bps, 8bit data, no parity, 1 stop bit

2. DATA FORMAT

Character String: 42 byte Format: (4-axis display)

X,Y,Z,Q: Axis data Start

xxxxxxxxx : X axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

yyyyyyyy : Y axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

zzzzzzzz: Z axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

qqqqqqqq: Q axis coordination value that has 9 digits including decimal point.

Decimal position can be moved according to its scale setting.

CR : carriage return(0x0d)

LF: line feed(0x0a)

(Ex.) X000132.00Y000001.00Z087234.00Q00123.097®①


X = 123.00, Y=1.00, Z = 87234.00, Q=123.097

®: CR, ①: LF

6. NC Scale Pin Assignment

| Counter (15-pin) | | Cable (9-pin) | | | |
|------------------|-----|---------------|-------|-----|-------|
| 2 PIN | RX | Green | 2 PIN | TX | White |
| 3 PIN | TX | White | 3 PIN | RX | Green |
| 5 PIN | GND | Black | 5 PIN | GND | Black |

Linear Scale



| 1 PIN | black | Vcc (+) 5V |
|-------|--------|--------------|
| 2 PIN | yellow | A |
| 3 PIN | white | B |
| 4 PIN | green | Ā |
| 5 PIN | brown | B |
| 6 PIN | pink | Z |
| 7 PIN | gray | Z |
| 8 PIN | shield | Shield (GND) |
| 9 PIN | blue | GND (-) 0V |





| Product | Digital Linear Scale (DRO) | Model | DSC800series |
|---------------------|----------------------------|------------------|--------------|
| Date of Purchase | | Serial number | |
| Agent | | Amount | |

| SER | VICE | RECORDOR SOME SOME SOME SOME SOME SOME SOME SOME | suggest for two y ulation fo r service g date ar | a limited wears from or the presence center as and the other | varranty against the date of ervation of defects were found, irs below blanks. |
|--|---|--|--|--|--|
| | | Product Digital Linear Scale (| DRO) | Model | DSC800series |
| | | Date of Purchase | | Serial number | |
| | | Agent | | Amount | |
| | KINDS | of DAMAGES | | | DETAILS |
| | KINDS | TOT DAWNALS | Wit wa | thin the rranty period | After the warranty period |
| | Functional or mechanical defects happened in normal operation | | Gra Exc | atuitous change | |
| Damage happened | Defects happened during shipping or installing | | | Ш | |
| in normal operation, or functional defect | | Recurrence of a trouble | | П | |
| | Repairable | Recurrence of same trouble for over 4 times continuously | П | | |
| | No repairable | In case of stop producing of parts, or other reason | | _ | Exchange for new model as compensation |
| | Defect caused f repairing and re | I rom careless handling or modeling. | (| Charged | Charged |
| Functional defect which caused from mishandling or | Defect caused from repairing by non authorized personnel. | | | П | П |
| misuse conducted on purpose by users. | Defect from applying non-allowable Voltage (use only AC 220V) | | | II | п |
| | Defect or broken from dropping down when moving it another place, after installation. | | | II | II. |
| Others | The cause of trouble is not from product itself but from exterior factor. | | | II . | П |
| In the case that the cause is from the natural calamity. When life span of consumable parts is almost done or over. | | | | | Charged |
| lease be informed t | <u> </u> | | Co., | Ltd. | |



