

DSC-Q01 (1axis display) user's manual



DSC-Q01



Contents

Description of DSC-Q01 counter

1. Front side	1-1
2. Rear side	1-2
3. Connection	1-3
4. Key description	1-4

Basic operation

1. Input (preset)	2-1
2. Display zero	2-1
3. ABS/INC conversion	2-1
4. ABS number designation	2-2

Function

1. Changing resolution	
(1) 5/1000	3-1
(2) 1/1000	3-1
(3) 1/100	3-2
(4) 5/10000	3-2
2. Changing process direction	3-3
3. Rate or correction	3-3
4. Double counting	3-5
5. Inch/mm conversion	3-5

6. Initializing

(1) ABS initializing	3-5
(2) Program initializing	3-6


7. Test	3-6
---------------	-----

Caution and trouble shooting

1. Caution	4-1
2. Trouble shooting	4-2
3. Pin information	4-3


*D*escription of DSC-Q01 counter

1. Front side




Keys	Description
1. Display area	shows position value
2. Axis selection key	select present axis
3. Axis-Zero key	make the display value zero
4. Power key	turn on / off the power
5. Number key	0~9 numbers
6. Function key	calls one of the functions

2. Rear side



Keys	Description
1. Power input 2. Connector	DC adapter input to connect with a scale

3. Connection




4. Description of the keys

Keys		Description
	Axis key	select axis
	Axis Zero key	make the axis zero
	Number key	input values
	Dot key	decimal point
	+/- key	+ - value conversion
	Function key	to call function menu
	Cancel key	cancel present processing or operation
	ABS function key	absolute function at any position
	Direction key	to move in the function or ABS numbers
	Enter key	completion of present process
	On/Off key	turn on / off the power

***B**asic operation*


1. Input value / Preset

 → input → 	
 <p>input "12.45"</p>       	
<p>input "-31.25"</p>        	

2. Display Zero

	it shows "0.000"
	
	

3. ABS / INC conversion (Absolute / Incremental)

 ABS	ABS designation key 99 ABS numbers can be saved. (1~99) Move in the numbers by using arrow keys. (← →)
conversion from INC(normal) to ABS  ABS	 "ABS 1" is flickering and disappeared. This means now in "ABS" mode.
conversion from ABS to INC(normal)  ABS	 "Inc" is flickering and disappeared. This means now in "INC" mode.
ABS and INC are changed in turn whenever  key pushed.	

4. Searching for one of the ABS numbers

 	move by arrow keys
<p>Ex. To find ABS number 5</p> <p>  . . .  </p> <p>push arrow key until 5 shows</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 2px 5px; margin-right: 10px;">ABS 1</div> <div style="text-align: center; margin-right: 10px;">↓</div> <div style="border: 1px solid black; padding: 2px 5px;">ABS 5</div> </div>	
<p>To find ABS number 1</p> <p>  . . .  </p> <p>push reverse arrow key until 1 shows</p> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; padding: 2px 5px; margin-right: 10px;">ABS 8</div> <div style="text-align: center; margin-right: 10px;">↓</div> <div style="border: 1px solid black; padding: 2px 5px;">ABS 1</div> </div>	
<ul style="list-style-type: none"> To input coordinates of the axis to an ABS number, type its value or "0.000" while the ABS number is shown. 	

*F*unction

Function

F

call function menu

F

1. Changing resolution (factory setting: 5/1000)
2. Direction change
3. Rate or correction
4. Double counting
5. Inch / mm conversion
6. Initialization
7. Test function

1. Changing resolution (menu>scale)

1. 5/1000

F → ENT → 5 → ENT	<ul style="list-style-type: none">▶ This resolution should be same as the scale's.▶ 5/1000 is basic factory setting.▶ After setting, "0.000" will be shown.	
F	SCALE	
ENT	5000	
5	5000	
ENT	0.000	

2. 1/1000

F → ENT → 1 → ENT	<ul style="list-style-type: none">▶ This resolution should be same as the scale's.▶ 5/1000 is basic factory setting.▶ After setting, "0.000" will be shown.	
F	SCALE	
ENT	5000	
1	1000	
ENT	0.000	

3. 1/100

<p>F → ENT → 1 → 0 → ENT</p>	<ul style="list-style-type: none"> ▶ This resolution should be same as the scale's. ▶ 5/1000 is basic factory setting. ▶ After setting, "0.000" will be shown. 								
<p>F</p> <p>ENT</p> <p>1 0</p> <p>ENT</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;"><i>SCALE</i></td> <td style="width: 50%;"></td> </tr> <tr> <td style="text-align: center;">5.000</td> <td></td> </tr> <tr> <td style="text-align: center;">10.000</td> <td></td> </tr> <tr> <td style="text-align: center;">0.000</td> <td></td> </tr> </table>	<i>SCALE</i>		5.000		10.000		0.000	
<i>SCALE</i>									
5.000									
10.000									
0.000									

4. 5/10000

<p>F → ENT → 0 → . → 5</p> <p>→ ENT</p>	<ul style="list-style-type: none"> ▶ This resolution should be same as the scale's. ▶ 5/1000 is basic factory setting. ▶ After setting, "0.0000" will be shown. 								
<p>F</p> <p>ENT</p> <p>0 . 5</p> <p>ENT</p>	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; text-align: center;"><i>SCALE</i></td> <td style="width: 50%;"></td> </tr> <tr> <td style="text-align: center;">5.000</td> <td></td> </tr> <tr> <td style="text-align: center;">0.500</td> <td></td> </tr> <tr> <td style="text-align: center;">0.0000</td> <td></td> </tr> </table>	<i>SCALE</i>		5.000		0.500		0.0000	
<i>SCALE</i>									
5.000									
0.500									
0.0000									

2. Direction change (menu>dir)

	+ or - direction change										
	<table border="1"> <tr> <td>F 0</td> <td>2d 1r</td> </tr> <tr> <td>ENT</td> <td>d 1r ---]</td> </tr> <tr> <td>9</td> <td>d 1r [----</td> </tr> <tr> <td>0</td> <td></td> </tr> <tr> <td>ENT</td> <td>0.000</td> </tr> </table>	F 0	2d 1r	ENT	d 1r ---]	9	d 1r [----	0		ENT	0.000
F 0	2d 1r										
ENT	d 1r ---]										
9	d 1r [----										
0											
ENT	0.000										

3. Rate or Correction (menu>rAtE)

	<ul style="list-style-type: none"> ▶ When there is a difference between the real distance and displayed distance. ▶ Basic rate is 1.000000 ▶ If you input 0.000000, there will be nothing displayed. 												
	<table border="1"> <tr> <td>F 0 0</td> <td>3r AtE</td> <td></td> </tr> <tr> <td>ENT</td> <td>1000000</td> <td>flickering</td> </tr> <tr> <td><i>input 1.0</i></td> <td>1000000</td> <td>1.0 or 1.000000</td> </tr> <tr> <td>ENT</td> <td>0.000</td> <td>instead, this rate ←</td> </tr> </table>	F 0 0	3r AtE		ENT	1000000	flickering	<i>input 1.0</i>	1000000	1.0 or 1.000000	ENT	0.000	instead, this rate ←
F 0 0	3r AtE												
ENT	1000000	flickering											
<i>input 1.0</i>	1000000	1.0 or 1.000000											
ENT	0.000	instead, this rate ←											

$$\text{Rate} = \frac{\text{real distance (dial/block gauge)}}{\text{displayed distance (numbers at the readout)}}$$

Ex.	Real distance is 100mm but the readout (a display) shows 100.4mm,	
	$\frac{100}{100.4} = 0.996$	
F 0 0		3r R t E
ENT		1000000 <i>flickering</i>
0 . 9 9 6		0996000 <i>type "0.996"</i>
ENT		0.000

4. Double counting (menu>dIA)

F → 0 → 0 → 0 → ENT	diameter ↔ radius
F 0 0 0	4d IA
ENT	r R d
0	d IA "dIA" is double of the radius
ENT	0.000

5. Inch / mm conversion (menu>Inch)

<p>F → 0 → 0 → 0 → 0 → ENT → 0 → ENT</p>	
<p>F 0 0 0 0 ENT 0 ENT</p>	<p>5. inch --nnnn-- -- inch-- 0.0000</p>

6. Initialization / Reset (menu>rESEt)

(1) ABS initialization

<p>F → 0 → 0 → 0 → 0 → 0 → ENT → ENT</p>	<p> Please note that all of the preset ABS data will be removed.</p>
<p>F 0 0 0 0 0 ENT ENT</p>	<p>6.rESEt 1.rSEt ABS 0.000</p>

(2) Program initialization / Reset

	<p>! Please note that all of the memorized data including ABS will be removed. All setting value returns to factory setting.</p> <p>Factory setting: resolution 5/1000 counting direction rate 1.000000 unit: mm radius</p>
--	--

F 0 0 0 0 0	6.rESEt	
ENT	1.rSt ABS	
0	2.rSt ALL	
ENT	0000	

7. Test function (menu>tEst)

	<p>Check if the LEDs are working well</p>	
F 0 0 0 0 0 0	7.tEst	
ENT	11111111	Counting up from 1 to 8
	0000	
CE	0000	

***C*aution and trouble shooting**

1. Caution



- Display counter and ground should be safely connected.
- To prevent malfunction or noise, please leave any electronic appliances away from the display counter.
- Please put any motor around the display counter.
- Please leave the display counter away from high voltage or where the temperature changes sharply.
- Please use only available voltage, AC 110V ~ 220V.

2. Trouble shooting


Troubles	Cause or Solutions
Power off / no power on	<ul style="list-style-type: none"> • Check if the power key(⏻) works well. • Check the power source • Check the connection state with the adapter. • Disconnect a scale from the counter and check.
There is a beep sound or keypad doesn't work.	<ul style="list-style-type: none"> • Mostly caused from inflowing of oils or fluids. • Needs to be replaced.
Inaccuracy problem	<ul style="list-style-type: none"> • Check the ground state. Noise can be a reason. • Check if the screws of the brackets are loosen. • Dusts or oils can cause inaccuracy; needs cleaning • Backlash of the machine tools can be another reason00. • Readhead, inside glass broken or connection failure can cause the problem: Needs to be replaced. • If there is same amount of error, regardless of distance, please do the correction. (see page 3-3 Rate or Correction)
It always shows double value.	<ul style="list-style-type: none"> • Check if the rate is set as 1.000000 (page 3-3) • Check if it is set as "double counting" function (page 3-4)
When the value is not changing or stands still at 0.000	<ul style="list-style-type: none"> • Do the program initialization (page 3-6)
Caution	<ul style="list-style-type: none"> • Be careful that oils or dusts not to flow into the keypad or linear scale.

※ This product can be modified without previous notice to improve quality.

3. PIN (6-pin) Information

Counter	Scale
	
1 PIN : + (+5V) 2 PIN : A 3 PIN : B 4 PIN : Z 5 PIN : - (0V) 6 PIN : Shield	1 PIN : + (+5V) 2 PIN : A 3 PIN : B 4 PIN : Z 5 PIN : - (0V) 6 PIN : Shield

PIN & Color



PIN	Color	Signal
1 PIN	RED	+ (+5V)
2 PIN	YELLOW	A (+4.2V)
3 PIN	WHITE	B (+4.2V)
4 PIN	GREEN	Z (+0.4V)
5 PIN	BLACK	- (+0V)
6 PIN	BLACK SHIELD	Shield (GND)

DC adapter spec.

Input	AC 100~240V / 60Hz, 0.6A
Output	DC5V = 1A
Size	Internal diameter: \varnothing 2.1mm External diameter: \varnothing 5.5mm

CERTIFICATE OF WARRANTY



- We, Dong Sahn JENIX Co., Ltd. suggest a limited warranty against various defects describes below for two years from the date of purchasing, according to the regulation for the preservation of consumer's right.
- Please contact the sales agent or service center as defects were found,
- Please put down your purchasing date and the others below blanks.

Product	Digital Linear Scale (DRO)	Model	DSC-Q01
Date of Purchase		Serial number	
Agent		Amount	

GUIDANCE FOR THE COMPENSATION OF CONSUMER'S DAMAGE

KINDS of DAMAGES		DETAILS		
		Within the warranty period	After the warranty period	
Damage happened in normal operation, or functional defect	Functional or mechanical defects happened in normal operation	Gratuitous Exchange		
	Defects happened during shipping or installing	"		
	Repairable	Recurrence of a trouble	"	
		Recurrence of same trouble for over 4 times continuously	"	
No repairable	In case of stop producing of parts, or other reason	—	Exchange for new model as compensation	
Functional defect which caused from mishandling or misuse conducted on purpose by users.	Defect caused from careless handling or repairing and remodeling.	Charged	Charged	
	Defect caused from repairing by non authorized personnel.	"	"	
	Defect from applying non-allowable Voltage (use only AC 220V)	"	"	
	Defect or broken from dropping down when moving it another place, after installation.	"	"	
Others	The cause of trouble is not from product itself but from exterior factor.	"	"	
<ul style="list-style-type: none"> ● In the case that the cause is from the natural calamity. ● When life span of consumable parts is almost done or over. 		Charged		

Please be informed this certificate is not reissued.



DONG SAHN JENIX CO., LTD.

Tel: (82)2-2625-2222

Fax: (82)2-2625-2228

E-mail: jenix@jenix.co.kr

web: www.jenix.co.kr

www.jenix.kr