

JENIX

JM Counter

INDICATOR FOR LINEAR GAUGE

English Manual

VER 2.6


V26-260212






DONG SAHN JENIX CO., LTD.



Contents

1. Channel A zero-setting	1
2. Channel B zero-setting	1
3. Channel A resolution setup	1
4. Channel B resolution setup	2
5. Upper limit setup	3
6. Lower limit setup	4
7. Mode setup	
1). Present value setup	5
2). Maximum value setup	5
3). Minimum value setup	6-1
4). P-P setup	6-1
5). LATCH setup	6-2
8. Process direction changing	7
9. Summing up function	8
10. Program reset / initialization	10
11. FND (7-segment) testing	11
12. PRESET	12
13. Multi limit setup & confirm	13
14. RS-232/485 setup	15
15. RS-232/485 transmission format	18
16. Communication velocity	22
17. Input/Output Circuit I	23
18. Input/Output Circuit II	24
19. Connector pin information	24
20. JMA-C1 Input/Output	25
21. JMA-C2 Input/Output	26











Keys	Summary
	Reset A or B channel to zero
	Set up upper / lower limit or input numbers
	Select or move the “PRESET”
	Renewal or move in HOLD mode
	Set up details or complete setup
	Select Present value, Maximum value, Minimum value or P-P value measuring modes.
	Cancel
LED	It shows whether it is normal by comparing the displayed value with the set upper/lower limit values. :Exceeded upper limit :Normal :Below the lower limit


Function	How to input																				
A channel Zero Setting																					
B channel Zero Setting																					
A channel Resolution setup																					
	<p>By using these keys  , try changing resolutions.</p>																				
	<table border="1" data-bbox="491 1039 986 1451"> <thead> <tr> <th>Resolution</th> <th>Display</th> </tr> </thead> <tbody> <tr><td>1</td><td>1</td></tr> <tr><td>5/10</td><td>0.5</td></tr> <tr><td>1/10</td><td>0.1</td></tr> <tr><td>5/100</td><td>0.05</td></tr> <tr><td>1/100</td><td>0.01</td></tr> <tr><td>5/1000</td><td>0.005</td></tr> <tr><td>1/1000</td><td>0.001</td></tr> <tr><td>5/10000</td><td>0.0005</td></tr> <tr><td>1/10000</td><td>0.0001</td></tr> </tbody> </table>	Resolution	Display	1	1	5/10	0.5	1/10	0.1	5/100	0.05	1/100	0.01	5/1000	0.005	1/1000	0.001	5/10000	0.0005	1/10000	0.0001
Resolution	Display																				
1	1																				
5/10	0.5																				
1/10	0.1																				
5/100	0.05																				
1/100	0.01																				
5/1000	0.005																				
1/1000	0.001																				
5/10000	0.0005																				
1/10000	0.0001																				
	 <ul style="list-style-type: none">  1/10000 setup  5/10000 setup  1/1000 setup  5/1000 setup  1/100 setup 																				



Function	How to input																				
B channel Resolution setup																					
	<p data-bbox="486 470 1356 593">By using these keys , try changing resolutions.</p> <table border="1" data-bbox="491 638 986 1079"> <thead> <tr> <th>Resolution</th> <th>Display</th> </tr> </thead> <tbody> <tr><td>1</td><td>1</td></tr> <tr><td>5/10</td><td>0.5</td></tr> <tr><td>1/10</td><td>0.1</td></tr> <tr><td>5/100</td><td>0.05</td></tr> <tr><td>1/100</td><td>0.01</td></tr> <tr><td>5/1000</td><td>0.005</td></tr> <tr><td>1/1000</td><td>0.001</td></tr> <tr><td>5/10000</td><td>0.0005</td></tr> <tr><td>1/10000</td><td>0.0001</td></tr> </tbody> </table>	Resolution	Display	1	1	5/10	0.5	1/10	0.1	5/100	0.05	1/100	0.01	5/1000	0.005	1/1000	0.001	5/10000	0.0005	1/10000	0.0001
Resolution	Display																				
1	1																				
5/10	0.5																				
1/10	0.1																				
5/100	0.05																				
1/100	0.01																				
5/1000	0.005																				
1/1000	0.001																				
5/10000	0.0005																				
1/10000	0.0001																				
																					



Function	How to input
Lower limit setup	

Function	How to input
Mode setup	
	1. Present value setup
	
	2. Maximum value setup
	 <p data-bbox="687 1491 916 1518">Now Maximum Mode</p>
	 <p data-bbox="560 1704 1318 1771">※ When the linear gauge is moving, the number will be holding at the maximum value.</p> 




Function	How to input
	<p data-bbox="480 226 1002 275">3. Minimum value setup</p> <div data-bbox="523 349 1425 719">  <p data-bbox="523 405 632 506">MODE →</p> <p data-bbox="708 349 810 577">A0 } B0 }</p> <p data-bbox="943 398 1050 506">▲ →</p> <p data-bbox="1066 405 1425 506">Lo hold (minimum value: LO HOLD)</p> <p data-bbox="647 613 810 719">→ SET</p> <p data-bbox="826 651 1054 680">Now Minimum Mode</p> </div> <div data-bbox="708 842 1497 931">  <p data-bbox="708 842 1066 931">- 0.5000</p> <p data-bbox="1075 869 1497 920">This indicates the minimum value that the linear gauge moved.</p> </div> <p data-bbox="628 958 1385 1043">※ When the linear gauge is moving, the number will be holding at the minimum value.</p> <div data-bbox="564 1077 1489 1182">  <p data-bbox="564 1077 735 1182">→ ▶</p> <p data-bbox="751 1077 1110 1182">0.0000</p> <p data-bbox="1118 1099 1489 1151">The minimum value disappeared, and present value displayed.</p> </div> <p data-bbox="480 1240 751 1290">4. P-P setup</p> <div data-bbox="469 1352 1477 1704">  <p data-bbox="469 1402 576 1503">MODE →</p> <p data-bbox="647 1352 751 1581">A0 } B0 }</p> <p data-bbox="868 1402 975 1503">▲ →</p> <p data-bbox="1002 1402 1361 1503">PP hold (Set to the difference value of the maximum and minimum values: PP HOLD)</p> <p data-bbox="584 1599 751 1704">→ SET</p> </div> <div data-bbox="772 1760 1278 1888">  <p data-bbox="772 1760 1129 1850">0.3250</p> <p data-bbox="671 1854 1278 1883">(difference value of the maximum and minimum values)</p> </div> <div data-bbox="517 1910 1461 2013">  <p data-bbox="517 1910 687 2013">→ ▶</p> <p data-bbox="708 1910 1066 2013">0.0000</p> <p data-bbox="1086 1921 1461 1995">previous "difference value" of the maximum and minimum values disappeared and "0" displayed.</p> </div>



Function	How to input
	<p data-bbox="475 226 820 277">5. LATCH setup</p>  <p data-bbox="587 636 751 705">→ SET</p> <p data-bbox="587 775 1326 875">→  "present value setup" updated</p>

Function	How to input
Process Direction Changing	 <p>SET → SET → A0 } select a channel (A or B) B0 } → [▲] } select one of two direction (UP or DOWN) [▼] } → SET</p>
	 <p>SET → [ld lr]</p> <p>→ SET → [d lr SEL]</p> <p>→ A0 (In case of A channel) → [d lr --] → [▲] } select a direction [▼] }</p> <p>→ B0 (In case of B channel) → [d lr --] → [▲] } select a direction [▼] }</p> <p>→ SET</p>



Function	How to input
Summing up function	 <p>selection of summing up channels</p>
	<p>1. Display A+B sum up value at B channel</p>  <p>sum up value of A+B shows in the B channel</p>

Function	How to input
	<p>2. Display A+B sum up value at A channel</p> <p>→ SET ld lr</p> <p>→ ▼ 2.Add</p> <p>→ SET A ch b ch</p> <p>→ ▲ } Add ch ← sum up value of A+B shows in the A channel ▼ } b ch</p> <p>→ SET</p>

Function	How to input
Program Reset (Initialization)	 <p>(move to #5)</p> <ul style="list-style-type: none"> • Please be careful. All of memorized data will be deleted.
	  <p>(move to #5)</p>   <p>※ Resolution will be set to 5/10000</p>



Function	How to input
FND (7-segment) testing	 <ul style="list-style-type: none"> • Checking defectiveness of FND <p>(move to #6)</p>
	 <p>in test, each FND number is increasing from 0 to 8.</p> <p>stop testing</p>

Function	How to input
PRESET	<p> P → A or B (select A or B channels) → P (to the left) } (to the right) } → ▲ } (adjust numbers) → MODE → SET ▼ } (when input “ - ”) </p>
	<p> P → A0 } → P <input type="checkbox"/> blinking (to the left) B0 } <input type="checkbox"/> blinking (to the right) (select A or B channels) </p> <p> → ▲ <input type="checkbox"/> 000.0000 → 000.0000 1 ○ ▼ <input type="checkbox"/> 000.0000 1 → 000.0000 ○ (adjust numbers) </p> <p> → MODE <input type="checkbox"/> 0.5000 → - 0.5000 ○ (use this when conversion + or -) </p> <p> → SET (save numbers) </p>

Function	How to input
<p>Multi-limit setup (In case of more than 1)</p>	
	 <p>※ By repeating above procedure, up to 16 (bound 0 ~ 15) can input.</p>

Function	How to input
Confirm saved Multi-limit value	<p>(2 sec)</p> <p>(wait for about 3sec)</p> <p>In the bound 0, upper limit value of A & B channels</p> <p>(A channel)</p> <p>(B channel)</p> <p>In the bound 0, lower limit value of A & B channels</p> <p>→ SET</p>

※ To see saved bound number(0~15),
 move to a number by using the ▲ ▼ keys and wait for 3 seconds.
Bound No., Upper limit value and Lower limit value are orderly displayed.

Function	How to input
RS232/485 One-way setup	 <p> SET → ▼ (3 times) → SET → SET → SET </p> <p> LCD displays: 4bus, 1TYPE, one-Asc </p>
<p>  Notice: To change communication option, the power should be off and on again. </p>	
RS232/485 Two-way setup (ASCII)	 <p> SET → ▼ (3 times) → SET → SET → ▼ → SET </p> <p> LCD displays: 4bus, 1TYPE, one-Asc, dup-b In </p>
<p>  Notice: To change communication option, the power should be off and on again. </p>	

Function	How to input
RS 485 Two-way setup (MODBUS)	<p>The diagram illustrates the sequence of button presses for the RS 485 Two-way setup (MODBUS) function. The sequence is as follows:</p> <ul style="list-style-type: none"> Press SET. Press down arrow (3 times). The display shows 4bus. Press SET. The display shows 1TYPE. Press SET. The display shows one-Asc. Press down arrow. The display shows dup-Asc. Press SET.



Notice:

To change communication option, the power should be off and on again.

※ Ref:

- 1) Modbus is recommendable for the interface with PLC.
- 2) To control multiple pieces with parallel connection, MODBUS should be used. The MODBUS is optional.

Function	How to input
RS-485 - MODBUS-id	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">SET</div> <div style="margin-right: 10px;">→</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">▼</div> <div style="margin-right: 10px;">(3 times)</div> <div style="border: 1px dashed black; padding: 5px; text-align: center;">4605</div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;">→</div> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">SET</div> <div style="border: 1px dashed black; padding: 5px; text-align: center;">1TYPE</div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;">→</div> <div style="border: 1px solid black; padding: 5px; text-align: center;">▼</div> <div style="border: 1px dashed black; padding: 5px; text-align: center;">3.1d</div> </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="margin-right: 10px;">→</div> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">SET</div> <div style="border: 1px dashed black; padding: 5px; text-align: center; width: 150px;">001</div> <div style="margin-left: 10px; font-size: small;">(available number: from 1 up to 247)</div> </div> <div style="border: 1px solid black; padding: 5px; margin: 10px 0; width: 150px; text-align: center;"> Assign ID number by using below keys </div> <div style="display: flex; flex-direction: column; align-items: center; margin-bottom: 10px;"> <div style="display: flex; align-items: center; margin-bottom: 5px;"> <div style="border: 1px solid black; padding: 5px; margin-right: 5px;">P</div> <div>(move a digit to the left)</div> </div> <div style="display: flex; align-items: center; margin-bottom: 5px;"> <div style="border: 1px solid black; padding: 5px; margin-right: 5px;">▶</div> <div>(move a digit to the right)</div> </div> <div style="display: flex; align-items: center; margin-bottom: 5px;"> <div style="border: 1px solid black; padding: 5px; margin-right: 5px;">▲</div> <div>(increase numbers)</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 5px;">▼</div> <div>(decrease numbers)</div> </div> </div> <div style="display: flex; align-items: center; margin-top: 10px;"> <div style="margin-right: 10px;">→</div> <div style="border: 1px solid black; padding: 5px;">SET</div> </div> </div>



Notice:

To change communication option, the power should be off and on again.

Function	How to input																														
<p>RS-232/485 transmission format - one way</p>	<p>Output method - DATA BIT: 8BiT - PARITY BIT: NO - STOP BIT: 1BiT</p> <p>Transmission method: ASCII</p> <p>Transmission format</p> <table border="1" data-bbox="491 539 1493 607"> <tr> <td>CHN</td> <td>Data</td> <td>Result</td> <td>CHN</td> <td>Data</td> <td>Result</td> <td>CR</td> <td>LF</td> </tr> </table> <p>Ex) Output "A=0.100, B=0.500"</p> <table border="1" data-bbox="491 741 1493 808"> <tr> <td>A</td> <td></td> <td></td> <td></td> <td>0</td> <td>.</td> <td>1</td> <td>0</td> <td>0</td> <td>H</td> <td>B</td> <td></td> <td></td> <td></td> <td>0</td> <td>.</td> <td>5</td> <td>0</td> <td>0</td> <td>L</td> <td>CR</td> <td>LF</td> </tr> </table> <p style="text-align: center;">  </p> <p>※ Result: H (High), N (Normal-OK), L (Low)</p>	CHN	Data	Result	CHN	Data	Result	CR	LF	A				0	.	1	0	0	H	B				0	.	5	0	0	L	CR	LF
CHN	Data	Result	CHN	Data	Result	CR	LF																								
A				0	.	1	0	0	H	B				0	.	5	0	0	L	CR	LF										
<p>※ Only "One to One" control is possible.</p>																															

Function	How to input																																																																		
RS-232 / 485 two-way format - ASCII	<p>Output method</p> <ul style="list-style-type: none"> - DATA BIT : 8Bit - PARITY BIT : NO - STOP BIT : 1Bit <p>Transmission method : ASCII</p> <p>Data transmission format:</p> <table border="1" style="display: inline-table; margin-left: 20px;"> <tr> <td style="width: 100px;">Data</td> <td style="width: 100px;">Result</td> <td style="width: 100px;">CR</td> <td style="width: 100px;">LF</td> </tr> </table> <p style="margin-left: 40px;">※ output "Result" only when reading each channel value</p> <p>Communication Command Format: [command] [CR] [LF]</p> <table border="1" style="width: 100%; margin-top: 10px;"> <thead> <tr> <th style="width: 15%;">Command</th> <th style="width: 85%;">Function</th> </tr> </thead> <tbody> <tr><td>@ ADDR</td><td>Read present address</td></tr> <tr><td>@ A</td><td>Read A channel value</td></tr> <tr><td>@ B</td><td>Read B channel value</td></tr> <tr><td>@ HIA</td><td>Read upper limit value of A channel</td></tr> <tr><td>@ HIB</td><td>Read upper limit value of B channel</td></tr> <tr><td>@ LOA</td><td>Read lower limit value of A channel</td></tr> <tr><td>@ LOB</td><td>Read lower limit value of B channel</td></tr> <tr><td>@ PRA</td><td>Read preset value of A channel</td></tr> <tr><td>@ PRB</td><td>Read preset value of B channel</td></tr> <tr><td>* ADDR number</td><td>Set up address value (0~15)</td></tr> <tr><td>* HIA number</td><td>Set up upper limit value of A channel</td></tr> <tr><td>* HIB number</td><td>Set up upper limit value of B channel</td></tr> <tr><td>* LOA number</td><td>Set up lower limit value of A channel</td></tr> <tr><td>* LOB number</td><td>Set up lower limit value of B channel</td></tr> <tr><td>* PRA number</td><td>Set up preset value of A channel</td></tr> <tr><td>* PRB number</td><td>Set up preset value of B channel</td></tr> <tr><td>* ZEROA</td><td>Set up present value of A channel to "0"</td></tr> <tr><td>* ZEROB</td><td>Set up present value of B channel to "0"</td></tr> <tr><td>* NEXT</td><td>Renewal to present value</td></tr> <tr><td>* PPA</td><td>Switch to PP mode of A channel</td></tr> <tr><td>* PPB</td><td>Switch to PP mode of B channel</td></tr> <tr><td>* MAXA</td><td>Switch to Hi mode of A channel</td></tr> <tr><td>* MAXB</td><td>Switch to Hi mode of B channel</td></tr> <tr><td>* MINA</td><td>Switch to LOW mode of A channel</td></tr> <tr><td>* MINB</td><td>Switch to LOW mode of B channel</td></tr> <tr><td>* LATA</td><td>Switch to LATCH mode of A channel</td></tr> <tr><td>* LATB</td><td>Switch to LATCH mode of B channel</td></tr> <tr><td>* SCANA</td><td>Switch to SCAN mode of A channel</td></tr> <tr><td>* SCANB</td><td>Switch to SCAN mode of B channel</td></tr> <tr><td>* S</td><td>Save present setup value</td></tr> </tbody> </table> <p style="margin-top: 10px;">※ Only "One to One" control is possible.</p>	Data	Result	CR	LF	Command	Function	@ ADDR	Read present address	@ A	Read A channel value	@ B	Read B channel value	@ HIA	Read upper limit value of A channel	@ HIB	Read upper limit value of B channel	@ LOA	Read lower limit value of A channel	@ LOB	Read lower limit value of B channel	@ PRA	Read preset value of A channel	@ PRB	Read preset value of B channel	* ADDR number	Set up address value (0~15)	* HIA number	Set up upper limit value of A channel	* HIB number	Set up upper limit value of B channel	* LOA number	Set up lower limit value of A channel	* LOB number	Set up lower limit value of B channel	* PRA number	Set up preset value of A channel	* PRB number	Set up preset value of B channel	* ZEROA	Set up present value of A channel to "0"	* ZEROB	Set up present value of B channel to "0"	* NEXT	Renewal to present value	* PPA	Switch to PP mode of A channel	* PPB	Switch to PP mode of B channel	* MAXA	Switch to Hi mode of A channel	* MAXB	Switch to Hi mode of B channel	* MINA	Switch to LOW mode of A channel	* MINB	Switch to LOW mode of B channel	* LATA	Switch to LATCH mode of A channel	* LATB	Switch to LATCH mode of B channel	* SCANA	Switch to SCAN mode of A channel	* SCANB	Switch to SCAN mode of B channel	* S	Save present setup value
Data	Result	CR	LF																																																																
Command	Function																																																																		
@ ADDR	Read present address																																																																		
@ A	Read A channel value																																																																		
@ B	Read B channel value																																																																		
@ HIA	Read upper limit value of A channel																																																																		
@ HIB	Read upper limit value of B channel																																																																		
@ LOA	Read lower limit value of A channel																																																																		
@ LOB	Read lower limit value of B channel																																																																		
@ PRA	Read preset value of A channel																																																																		
@ PRB	Read preset value of B channel																																																																		
* ADDR number	Set up address value (0~15)																																																																		
* HIA number	Set up upper limit value of A channel																																																																		
* HIB number	Set up upper limit value of B channel																																																																		
* LOA number	Set up lower limit value of A channel																																																																		
* LOB number	Set up lower limit value of B channel																																																																		
* PRA number	Set up preset value of A channel																																																																		
* PRB number	Set up preset value of B channel																																																																		
* ZEROA	Set up present value of A channel to "0"																																																																		
* ZEROB	Set up present value of B channel to "0"																																																																		
* NEXT	Renewal to present value																																																																		
* PPA	Switch to PP mode of A channel																																																																		
* PPB	Switch to PP mode of B channel																																																																		
* MAXA	Switch to Hi mode of A channel																																																																		
* MAXB	Switch to Hi mode of B channel																																																																		
* MINA	Switch to LOW mode of A channel																																																																		
* MINB	Switch to LOW mode of B channel																																																																		
* LATA	Switch to LATCH mode of A channel																																																																		
* LATB	Switch to LATCH mode of B channel																																																																		
* SCANA	Switch to SCAN mode of A channel																																																																		
* SCANB	Switch to SCAN mode of B channel																																																																		
* S	Save present setup value																																																																		

Function	How to input
----------	--------------

RS- 485 two-way format

① Transmission method: MODBUS RTU

② Transmission format: Compliance with MODBUS standards

③ Communication format:

Parity None

Stop bits 1



FUNC	
Read Input register	04
Read Holding register	03
Write Single Register	06
Write Multi Register	16

Address	FUNC	R/W	Explication	Contents		
30001	04	R	CH-A number L	32Bit Integer type (binary code)		
30002	04	R	CH-A number H			
30003	04	R	CH-B number L			
30004	04	R	CH-B number H			
30005	04	R	Model name	C2		
30006	04	R	Hardware version	1		
30007	04	R	Software version	1		
30008	04	R	Reserved			
30009	04	R	FLAG	BIT	Contents	Behavior
				[1:0]	CH-A discriminant	0: LOW
				[3:2]	CH-B discriminant	1:NORMAL
						2:HIGH
40010	03/06/16	R/W	CTR	[0]	ZERO A	A/B CH ZERO setup
				[1]	ZERO B	
				[7]	NEXT	present value renewal
40011	03/06/16	R/W	ADD	BIT	Contents	Behavior
				[1:0]	ADD mode	0: CH-A / CH-B 1:ADD / CH-B 2:CH-A / ADD
			MODE_A	[4:2]	HOLD mode	0:SCAN mode 1: MAX mode 2: MIN mode
			MODE_B	[7:5]		3: P-P mode 4: LATCH mode
40012	03/06/16	R/W	UART ID	available 1~247		
40013	03/06/16	R/W	address asignment	available 0~15		

Function		How to input				
Address	FUNC	R/W	Explication	Contents		
				BIT	Contents	Behavior
40014	03/06/16	R/W	SCALE A	[4:0]	Resolution change	1:1mm
						2:0.5mm
						3:0.1mm
						4:0.05mm
						5:0.01mm
						6:0.005mm
						7:0.001mm
						8:0.0005mm
				9:0.0001mm		
				[7]	Direction change	
40016	03/06/16	R/W	SAVE	[0]	Save	1:Save
40017	03/06/16	R/W	Preset L	CH-A address 0		
40018			Preset H			
40019			Upper limit L			
40020			Upper limit H			
40021			Lower limit L			
40022			Lower limit H			
...				
40107	03/06/16	R/W	Preset L	CH-A address 15		
40108			Preset H			
40109			Upper limit L			
40110			Upper limit H			
40111			Lower limit L			
40112			Lower limit H			
...				
40113	03/06/16	R/W	Preset L	CH-B address 0		
40114			Preset H			
40115			Upper limit L			
40116			Upper limit H			
40117			Lower limit L			
40118			Lower limit H			
...				
40203	03/06/16	R/W	Preset L	CH-B address 15		
40204			Preset H			
40205			Upper limit L			
40206			Upper limit H			
40207			Lower limit L			
40208			Lower limit H			

※ Ref:



- 1) To control multiple pieces with parallel connection, MODBUS should be used.
- 2) MODBUS is highly recommended for interface with PLC.

Function	How to input									
Communication Velocity Setup										
	 <table border="1" data-bbox="1139 1435 1450 1843"> <thead> <tr> <th>communication velocity</th> </tr> </thead> <tbody> <tr><td>4800</td></tr> <tr><td>9600</td></tr> <tr><td>14400</td></tr> <tr><td>19200</td></tr> <tr><td>28800</td></tr> <tr><td>38400</td></tr> <tr><td>57600</td></tr> <tr><td>115200</td></tr> </tbody> </table>	communication velocity	4800	9600	14400	19200	28800	38400	57600	115200
communication velocity										
4800										
9600										
14400										
19200										
28800										
38400										
57600										
115200										



Notice:


To change communication option, the power should be off and on again.

Function	How to input
Input / Output Circuit	<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <h3>1. Input Circuit</h3> <ul style="list-style-type: none"> • Input Items - OFF voltage: OPEN - ON voltage: Short </div> <div style="width: 50%;"> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Counter</p>  </div> <div style="text-align: center;"> <p>External signal</p>  </div> </div> </div> </div>


2. Output Circuit

JMA-C1

Counter




External




JMA-C2

Counter



External



 **Notice:**
 24V is Output terminal.
 Do not connect(input) voltage.


▣ Mounting a linear gauge
(JMA-13(B)L)



Notice: Assembling with excessive force during installation can damage the gauge.

example of using
a $\phi 12$ collet

example of using
a $\phi 8$ collet




※ If the contact point is to be removed, be sure to lift the bellows up, hold the exposed shaft, and turn the contact point to separate them.



- Notice:
1. If + - of the power is changed, indicator will be damaged.
 2. The radius of curvature of the cable must be installed at least 30mm, (over 30mm) when wiring the cable of the linear gauge.


19.Pin Assignment ($\phi 8-6$ PIN)		
Pin No.	Color	Signal
1	Red	+ (5V)
2	Yellow	DATA -
3	White	DATA +
4	Green	CLK -
5	Blue	CLK +
6	Black	- (0V)

JMA-C1



Title	PIN	Explication												
RS-232/485	1 : GND	RS-232		RS-485										
	2 : TX	JMA-C2	D-SUB 9PIN	JMA-C2	D-SUB 9PIN									
	3 : RX	<table border="0"> <tr> <td>1 GND</td> <td>2 TX</td> </tr> <tr> <td>2 TX</td> <td>3 RX</td> </tr> <tr> <td>3 RX</td> <td>5 GND</td> </tr> </table>	1 GND	2 TX	2 TX	3 RX	3 RX	5 GND	<table border="0"> <tr> <td>1 GND</td> <td>2 485+</td> </tr> <tr> <td>2 485+</td> <td>3 485-</td> </tr> <tr> <td>3 485-</td> <td>5 GND</td> </tr> </table>	1 GND	2 485+	2 485+	3 485-	3 485-
1 GND	2 TX													
2 TX	3 RX													
3 RX	5 GND													
1 GND	2 485+													
2 485+	3 485-													
3 485-	5 GND													
※for IBM PC Standard														
SIG-IN	1 : GND	GND												
	2 : A0	Display A channel as "0".												
	3 : B0	Display B channel as "0".												
	4 : ►	In the Holding mode, renew present value.												
SIG-OUT	1 : 24V	Voltage +12V ~ +24V												
	2 : GND	GND												
	3 : A-HI	A channel upper limit signal output												
	4 : A-GO	A channel normal signal output												
	5 : A-LO	A channel lower limit signal output												
DC-IN	+V	Input voltage +12V ~ +24V												
	0V	GND												
	FG	FG (shield)												

JMA-C2



Title	PIN	Explication																										
RS-232/485	1 : GND	RS-232		RS-485																								
	2 : TX	JMA-C2	D-SUB 9PIN	JMA-C2	D-SUB 9PIN																							
	3 : RX	<table border="1"> <tr><td>1</td><td>GND</td></tr> <tr><td>2</td><td>TX</td></tr> <tr><td>3</td><td>RX</td></tr> </table>	1	GND	2	TX	3	RX	<table border="1"> <tr><td>2</td><td>TX</td></tr> <tr><td>3</td><td>RX</td></tr> <tr><td>5</td><td>GND</td></tr> </table>	2	TX	3	RX	5	GND	<table border="1"> <tr><td>1</td><td>GND</td></tr> <tr><td>2</td><td>485+</td></tr> <tr><td>3</td><td>485-</td></tr> </table>	1	GND	2	485+	3	485-	<table border="1"> <tr><td>2</td><td>485+</td></tr> <tr><td>3</td><td>485-</td></tr> <tr><td>5</td><td>GND</td></tr> </table>	2	485+	3	485-	5
1	GND																											
2	TX																											
3	RX																											
2	TX																											
3	RX																											
5	GND																											
1	GND																											
2	485+																											
3	485-																											
2	485+																											
3	485-																											
5	GND																											
※for IBM PC Standard																												
SIG-IN	1 : GND	GND																										
	2 : A0	Display A channel as "0".																										
	3 : B0	Display B channel as "0".																										
	4 : ►	In the Holding mode, renew present value.																										
SIG-OUT	1 : 24V	Voltage +12V ~ +24V																										
	2 : GND	GND																										
	3 : A-HI	A channel upper limit signal output																										
	4 : A-GO	A channel normal signal output																										
	5 : A-LO	A channel lower limit signal output																										
	6 : B-HI	B channel upper limit signal output																										
	7 : B-GO	B channel normal signal output																										
	8 : B-LO	B channel lower limit signal output																										
DC-IN	+V	Input voltage +12V ~ +24V																										
	0V	GND																										
	FG	FG (shield)																										

CERTIFICATE OF WARRANTY

SERVICE

- We, Dong Sahn JENIX Co., Ltd. suggest a limited warranty against various defects describes below for two years from the date of purchasing, according to the regulation for the preservation of consumer's right.
- Please contact the sales agent or service center as defects were found.
- Please put down your purchasing date and the others below blanks.

Product	Linear Gauge	Model	JMA series
Date of Purchase		Serial number	
Agent		Amount	

GUIDANCE FOR THE COMPENSATION OF CONSUMER'S DAMAGE

KINDS of DAMAGES		DETAILS		
		Within the warranty period	After the warranty period	
Damage happened in normal operation, or functional defect	Functional or mechanical defects happened in normal operation	Gratuitous Exchange		
	Defects happened during shipping or installing	"		
	Repairable	Recurrence of a trouble	"	
		Recurrence of same trouble for over 4 times continuously	"	
No repairable	In case of stop producing of parts, or other reason	—	Exchange for new model as compensation	
Functional defect which caused from mishandling or misuse conducted on purpose by users.	Defect caused from careless handling or repairing and remodeling.	Charged	Charged	
	Defect caused from repairing by non authorized personnel.	"	"	
	Defect from applying non-allowable Voltage (use only AC 220V)	"	"	
	Defect or broken from dropping down when moving it another place, after installation.	"	"	
Others	The cause of trouble is not from product itself but from exterior factor.	"	"	
<ul style="list-style-type: none"> ● In the case that the cause is from the natural calamity. ● When life span of consumable parts is almost done or over. 		Charged		

Please be informed this certificate is not reissued.

DONG SAHN JENIX CO., LTD.

Tel:82-2-2625-2222 Fax: 82-2-2625-2228 jenix@jenix.co.kr

JENIX.CO.KR